



JOHNSTON COUNTY PROJECT LIFESAVER

Battery Changing Instruction for Caregiver

- 1. Ensure you have all materials needed to change batteries** (*safety scissors, key, sharpie, wipes, new battery, silicone, new band, battery tester, and new caregiver log*)
- 2. Cut the existing band off** (*try to distract so the individual doesn't see how you are cutting it off to prevent unwanted removal*)
- 3. Open the Transmitter** with the provided key
- 4. Use a Sharpie to mark an X on the old battery** before removing
- 5. Check and record** on the Caregiver Log the frequency number
- 6. Clean the cap and O ring** around the cap with wipe. Use caution to not stretch or remove the O ring.
- 7. Clean the threads of the transmitter case.** DO NOT attempt to clean the open area of the transmitter as it should remain dry.
- 8. Use a tiny amount of silicone** around ONLY the cap of the transmitter. (About the size of a pea)
- 9. Place the new battery** in the transmitter, positive (+) side up
- 10. Replace the transmitter cap** with key and tighten
- 11. Use the batter tester** to ensure transmitter is functioning
- 12. Attach band** to the transmitter
- 13. Secure it** on the DOMINANT wrist or ankle.

Watch The Instructional Video:

johnstonnc.gov/plchangebattery

